

TOPRITE WORKTOPS

DUROPAL MATCHING ABS/ PP EDGINGS

U11026 MS Crystal White U1026
U11027 XM Icy White U1027
U12188 XM Light Grey
R20004 VV Natural Oak Block R4101
R20016 VV Harvard Oak Block R4210
R20039 RU Sonoma Oak R4285
R20065 NW Dark Mountain Oak R4371
R20090 RU Lambrate R5836
R24022 VV White Beech Parquet R5336
R30023 VV Block Walnut R5151
R30027 VV Woodmix Block R5989
R45004 VV Plum Butcherblock R5638
R50003 RU Clay Sangha Wenge R5612
R50004 RU Nat Sangha Wenge R5613
R55004 RU Ponderosa Pine
S61000 FG Grey Ottawa R6050
S61001 FG Brown Ottawa R6052
S61008 TC Black Brazil R6216
S61011 CT Ipanema White R6265
S61013 CT Ipanema Grey R6267
S62008 VV Brown Sahara R6457
S62009 CT Natural Messina R6461
S62010 CT Antique Messina R6462
S62011 CT Taurus Sand R6482
S63003 TC Light Marble R6254
S63011 TC Jura Marble R6442
S63014 HS Roma Marble Gloss R6499
S64004 FG Welsh Slate R6487
S66000 TC Star Black F7407
S66010 TC Mirabelle Corro R6352
S66012 MS Glacial Storm R6480
S68000 TC Anthracite Peru F7646
S68002 TC Astral Quartz F8345
S68002 HS Astral Quartz Gloss F8345
S68004 CT Tivoli R6244
S68013 TC Black Limestone R6424
F73009 CT Quartz Stone F7655
F73010 TC Dark Anthracite Fino F7684
F76016 CT Flash Black F7654
F76023 VV Brushed Aluminium F8110
F76044 XM Bellato Grey

Duropal pattern numbers have been changed and now have five numbers. The old code is shown in blue.

The texture on the PP/ABS edge is not always the same as the texture of the worktop

Updated February 2018